

SiPass Integration - DVTel as the Front End


Professional Engineering Services

DVTel's Professional Engineering Services (PES) Group provides custom automation and operation and 3rd party integration to DVTel's intelligent Security Operations Center (iSOC) platform so that every DVTel solution has the ability to be tailored to meet the requirements of the customer.

Siemens provides the SiPass access control solution. This integration is between SiPass and DVTel's Latitude Network Video Management System (NVMS).


You can add the SiPass Access Control Server in Admin Center Physical View.

Access control entities are displayed in the Admin Center physical tree and the readers are displayed in Admin Center logical tree and in ControlCenter.




Configuring Latitude Responses to SiPass Events

Using the Alarms and Events widget in Admin Center user can set of the four Latitude responses; the four responses are Alarm, Event, Runtime, Ignore. User can add new access control events to the Alarm and Events widget. User can configure actions (start recording, go to PTZ preset...) to be executed along with alarm or event.



You can associate a camera to a specific reader. Readers in Control Center can either be double clicked or drag and dropped to an available tile and the associated camera will display live view. If an alarm is triggered due to a specific reader event, camera will start recording and if control center tile has been arm for alarm a live view of the camera will pop in the tile.



Status of SiPass Entities

SiPass entities status (Offline, Communicating, Synchronizing, Communication Lost) is displayed in the General Tab in Admin Center.

Integration Supports Multiple Directories


User can configure multiple DVTel's Latitude NVMS systems and Siemens's SiPass access control system.

SiPass Integration - SiPass as the Front End

Professional Engineering Services

When SiPass is the front end:

- Can view cameras connected to Latitude within SiPass interface.
- Can view live or recorded video from Cameras connected to Latitude within SiPass interface
- Play Back from DVR. Playback Control for a recorded video, select the desired date and time and hit the “Goto” button. To pause the playing playback, hit the “Stop” button.
- You can start recording on the selected camera by hitting the “Start” button and stop recording by hitting the “Stop” button.
- Control PTZ, Presets, Focus Near, Focus Far for a PTZ enabled camera
- You can clear, set, or go to a preset.
- Status Bar displays camera id on the left side, the right side displays current time of the playing video and the recording status of the camera that the video belongs to. Red if camera is recording and Green if camera is not recording.



SiPass Audit Trail

Can Play Back recorded video from the Audit Trail.

Camera events like MotionOn, Motion Off Event, Accessibility Lost, Accessibility Recovered are displayed in the Audit Trail

Image Verification

You can configure to view Live video from a camera upon Card Transaction

Site Plans and Event Tasks

You can configure Site Plans and Event tasks to view live video or to record a camera.